

Bintracker



B5000PC0001

BAG
PAPER & CARDBOARD

Scan Here
for more information



Mobi Info

Battery Handling

Follow the battery guidelines provided in the manual. Do not expose batteries to extreme temperatures or attempt to disassemble.

Device Handling

Use the Mobi device only for its intended purpose. Avoid dropping or subjecting it to heavy impact.

Wireless Charging

When using the wireless charging feature, ensure the mobile device is compatible and properly positioned on the charging pad.

Cleaning

Clean the Mobi device with a dry or slightly damp cloth. Do not immerse it in water or use harsh cleaning agents.

Maintenance

Regularly inspect the Mobi device for any signs of damage. If damaged, discontinue use and contact customer support.

support@bintracker.com.au

Mobi SCALES



Download Bintracker
Powered by gurru

1. Go to the App/Google Play Store
2. Search Bintracker

1. Power On




- I. Ensure **Bintracker** app is installed and open on device.
- II. Select the **Green** Power button to turn on the **Mobi Scales**.

2. Collect Waste



- I. Tie-up waste bags and hook them onto the **Mobi Scales**.
- II. Scan QR Codes & Weigh waste using the **Bintracker** app.



Bintracker



B5000GW0001

Bintracker



B5000CO0001

Bintracker



B5000OR0001

BAG
GENERAL WASTE

BAG
MIXED RECYCLING

BAG
ORGANICS